

WESTERN PINE

SEE THRU SHALLOW

LOG DIAGRAM

WPS1805SS

Step 1

(Top View)



Step 2

(Front View)

(Back View)



Step 3

(Front View)

(Back View)



WESTERN PINE

SEE THRU SHALLOW LOG DIAGRAM

WPS1805SS

Final

(Top View)



WESTERN PINE

SEE THRU SHALLOW

LOG DIAGRAM

WPS2407SS

Step 1 (Top View)



Step 2

(Front View)



(Back View)



Step 3

(Front View)



(Back View)



WESTERN PINE
SEE THRU SHALLOW
LOG DIAGRAM

Final

(Top View)



WESTERN PINE

SEE THRU SHALLOW

LOG DIAGRAM

WPS3008SS

Step 1


(Top View)



Step 2

(Front View)

(Back View)



Step 3

(Front View)

(Back View)



WESTERN PINE

SEE THRU SHALLOW LOG DIAGRAM

WPS3008SS

Final

(Top View)



WESTERN PINE

INDIVIDUAL LOG

DIAGRAM

1509GO



1510GO



1511GO



1512GO



1514GO



1515GO



1516GO



1517GO



1518GO



1520GO



1522GO



WESTERN PINE

INDIVIDUAL LOG DIA- GRAM

1524GO



1525GO



1529GO



1530GO



1536GO



1542GO

1548GO

