

WESTERN PINE

SEE-THRU LOG DIAGRAM

WPS1806ST

Step 1

(Top View)



Step 2

(Front View)

(Back View)



Step 3

(Front View)

(Back View)



092921


WESTERN PINE

SEE-THRU LOG DIAGRAM

WPS1806ST

Final

(Top View)



WESTERN PINE

SEE-THRU LOG DIAGRAM

WPS2107ST

Step 1

(Top View)



Step 2

(Front View)

(Back View)



Step 3

(Front View)

(Back View)




WESTERN PINE

SEE-THRU LOG DIAGRAM

WPS2107ST

Final

(Top View)



WESTERN PINE

SEE-THRU LOG DIAGRAM

WPS2409ST

Step 1

(Top View)



Step 2

(Front View)

(Back View)



Step 3

(Front View)

(Back View)



WESTERN PINE

SEE-THRU LOG DIAGRAM

WPS2409ST

Final

(Top View)



WESTERN PINE

SEE-THRU LOG DIAGRAM

WPS3009ST

Step 1

(Top View)



Step 2

(Front View)

(Back View)



Step 3

(Front View)

(Back View)




WESTERN PINE

SEE-THRU LOG DIAGRAM

WPS3009ST

Final

(Top View)



WESTERN PINE

SEE-THRU LOG DIAGRAM



WPS3610ST

Step 1 (Top View)




Step 2 (Front View)

(Back View)



Step 3 (Front View)

(Back View)



WESTERN PINE


SEE-THRU

WPS3610ST

LOG DIAGRAM

Final

(Top View)



WESTERN PINE

INDIVIDUAL LOG DIAGRAM

1509GO



1510GO



1511GO



1512GO



1514GO




1515GO



1516GO



1517GO



1518GO



1520GO



1522GO



WESTERN PINE

INDIVIDUAL LOG DIAGRAM

1524GO



1525GO



1529GO



1530GO



1536GO



1542GO



1548GO

