WESTERN PINE

SEE THRU SHALLOW

WPS1805SS LOG DIAGRAM

Step 1 (Top View)





Step 2 (Front View) (Back View)





Step 3 (Front View) (Back View)





092421

WESTERN PINE

SEE THRU SHALLOW

WPS1805SS LOG DIAGRAM

Final **(Top View)**



WESTERN PINE

SEE THRU SHALLOW

WPS2105SS LOG DIAGRAM

Step 1 (Top View)



Step 2 (Front View) (Back View)





Step 3 (Front View) (Back View)





WESTERN PINE

SEE THRU SHALLOW

WPS2105SS LOG DIAGRAM

Final **(Top View)**



WESTERN PINE

SEE THRU SHALLOW

WPS2407SS LOG DIAGRAM

Step 1 (Top View)



Step 2 (Front View) (Back View)





Step 3 (Front View) (Back View)





WESTERN PINE

SEE THRU SHALLOW

WPS2407SS LOG DIAGRAM

Final **(Top View)**



WESTERN PINE


SEE THRU SHALLOW


WPS3008SS LOG DIAGRAM

Step 1 (Top View)



Step 2 (Front View) (Back View)





Step 3 (Front View) (Back View)





WESTERN PINE

SEE THRU SHALLOW

WPS3008SS LOG DIAGRAM

Final **(Top View)**



WESTERN PINE
INDIVIDUAL
LOG DIAGRAM

1509GO



1510GO



1511GO



1512GO



1514GO



1515GO



1516GO



1517GO



1518GO



1520GO



1522GO



WESTERN PINE
INDIVIDUAL
LOG DIAGRAM

1524GO



1525GO



1529GO



1530GO



1536GO



1542GO



1548GO

